

Names of Parts

Shape of the tip. The preferred method of adjustment uses a tip thermometer *(See "Calibrating the Iron Temperature")* .

Troubleshooting Guide

WARNING!

Disconnect the power plug before servicing. Failure to do so may result in electric shock.

If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarity qualified person in order to avoid personal injury or damage to the unit.